



EMINENT



EM8625
Wireless signal repeater

en

Manual

EM8625 - Wireless signal repeater

Table of contents


1.0 Introduction	2
2.0 Description	2
2.1 LED indicators	3
3.0 Where to place the wireless repeater ?	3
4.0 Add or delete accessories	3
4.1 Add accessories	4
4.2 Add wireless siren	4
4.3 Delete accessories	4
5.0 Frequently Asked Questions and other related information	4
6.0 Service and support	5
7.0 Warning and points of attention	5
8.0 Warranty conditions	7

1.0 Introduction

Congratulations with the purchase of this high-quality Eminent product! This product has undergone extensive testing by Eminent's technical experts. Should you experience any problems with this product, you are covered by Eminent warranty. Please keep this manual and the receipt in a safe place.

Register your product now on www.eminent-online.com and receive product updates!

2.0 Description



2.1 LED indicators

The LED indicators are inside of the learning button.
Once the repeater is switched on the LED indicator will be lit.

LED Green : The wireless repeater is switched on

LED Blue : The wireless repeater is transmitting data

When both Green en Blue LEDs are flashing, the repeater is in learning or deleting modus.

3.0 Where to place the wireless repeater ?

The signal repeater should be placed at the correct location.

The distance between the repeater and the control panel should be maximum 300meters (open field). The distance between the repeater and the accessories should be maximum 90meters (open field).

In below picture you can see the correct location. The motion detector is used as a sample accessory.



4.0 Add or delete accessories

Each accessory which needs to connect to the alarm system through this wireless repeater should be paired to the repeater.

Note : First you need to pair the accessory with the alarm system itself !

To add or delete an accessory from the wireless repeater you should set the repeater in learning or deleting mode.

Switch the repeater ON to activate the learning mode. When the repeater is already ON, please switch it OFF and ON again. The repeater will go into learning mode now for about one minute. The Green and Blue LEDs are flashing.

4.1 Add accessories

When the repeater is in learning mode, press the learning button once and trigger the accessory you would like to connect (please refer to the manual of the accessory). The Blue LED indicator will be lit for about 2 seconds. The repeater has added the accessory successfully.

If you would like to add another accessory, please repeat the steps above.



Note: if the repeater does not receive a signal from the accessory within one minute, it will exit the learning mode automatically.

4.2 Add wireless siren

When the repeater is in learning mode, press the learning button once. Now press the SOS button on the remote control of the alarm system. The Blue LED indicator will be lit for about 2 seconds. The repeater has added the wireless siren successfully.



4.3 Delete accessories

When the repeater is in learning mode, press and hold the learning button for 5 seconds. The Blue LED indicator will be lit for about 2 seconds. The repeater has deleted all paired accessories successfully.

5.0 Frequently Asked Questions and other related information

The latest Frequently asked questions for your product can be found on the support page of your product. Eminent will update these pages frequently to assure you have the most recent information. Visit www.eminent-online.com for more information about your product.

6.0 Service and support

This user manual has been carefully written by Eminent's technical experts. If you have problems installing or using the product, please fill out the support form at the website www.eminent-online.com/support.

You can also contact us by phone. Please check www.eminent-online.com/support for the helpdesk phone number and opening hours.

7.0 Warning and points of attention



Due to laws, directives and regulations set out by the European parliament, some (wireless) devices could be subject to limitations concerning its use in certain European member states. In certain European member states the use of such devices could be prohibited. Contact your (local) government for more information about this limitations.

Always follow up the instructions in the manual*, especially where it concerns devices which need to be assembled.

Warning: In most cases this concerns an electronic device. Wrong/improper use may lead to (severe) injuries!

When you connect the device to the mains, make sure it will not be damaged or subject to (high) pressure.

A power socket is needed which should be close and easy accessible from the device.

Repairing of the device should be done by qualified Eminent staff. Never try to repair the device yourself. The warranty immediately voids when products have undergone self-repair and/or by misuse. For extended warranty conditions, please visit our website at www.eminent-online.com/warranty.

Dispose of the device appropriately. Please follow your countries regulation for the disposal of electronic goods.

Please check below safety points carefully:

- Do not apply external force on the cables
- Do not unplug the device by pulling the power cable
- Do not place the device near heating elements
- Do not let the device come in contact with water of other liquids
- If there is any strange sound, smoke or odor, remove the device immediately from the power outlet.
- Do not put any sharp objects into the venting hole of a product
- Do not use any damaged cables (risk of electric shock)

- Keep the product out of reach of children
- Wipe off the product with soft fabric, not water mop.
- Keep the power plug and outlet clean
- Do not unplug the device from the power outlet with wet hands
- Unplug the device when you don't use it for a long time
- Use the device at a well ventilated place

**Tip: Eminent manuals are written with great care. However, due to new technological developments it can happen that a printed manual does not longer contain the most recent information. If you are experiencing any problems with the printed manual or you cannot find what you are looking for, please always check our website www.eminent-online.com first for the newest updated manual.*

Also, you will find frequently asked questions in the FAQ section. It is highly recommended to consult the FAQ section. Very often the answer to your questions will be found here.

8.0 Warranty conditions

The Eminent warranty applies to all Eminent products. After buying a second-hand Eminent product the remaining period of warranty is measured from the moment of purchase by the product's initial owner. Eminent warranty applies to all Eminent products and parts, indissolubly connected or mounted to the product it concerns. Power supply adapters, batteries, antennas and all other products not directly integrated in or connected to the main product or products of which, without reasonable doubt, can be assumed that wear and tear during use will show a different pattern than the main product, are not covered by the Eminent warranty. Products are not covered by the Eminent warranty when exposed to incorrect/improper use, external influences or when opening the service parts of the product by parties other than Eminent. Eminent may use refurbished materials for repair or replacement of your defective product. Eminent cannot be held responsible for changes in network settings by internet providers. We cannot guarantee that the Eminent networking product will keep working when settings are changed by the internet providers. Eminent cannot guarantee the working of web services, apps and other third party content that is available through Eminent products.

When my product gets defective

Should you encounter a product rendered defective for reasons other than described above: Please contact your point of purchase for taking care of your defective product.



Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.
The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Eminent is a member of the Intronics Group